



1812 SERIES TELEPHONE ENTRY + ACCESS CONTROL SYSTEMS



UNIQUE SYSTEM ALLOWS HOMEOWNERS TO USE THEIR TELEPHONE AS AN INTERCOM TO SPEAK WITH VISITORS AT THEIR FRONT DOOR OR GATE



flush mount

wall mount

surface mount

surface mount curved

- Three models to choose from: 1812 Classic, 1812 Plus, and 1812 Access Plus
- Unique Communication and Access Control System allows homeowners to use their telephone as an intercom to speak to a guest at a front door or gate
- System connects directly to the homeowner's existing telephone line. No additional monthly expenses for a separate telephone line
- Calls from Access System are identified with a double ring. Homeowners know instantly if a call is coming from their door or gate
- Built-In Call Waiting assures that incoming or guest calls are not missed
- 2-Year Limited Factory Warranty



grant guest access
by pressing 9 on the telephone



additional
access point control with keypads,
card readers or RF receiver




modular design
makes installation and service easy




pc programmable
program the 1812 Access Plus from your PC

ACCESS CONTROL SOLUTIONS


1812 SERIES TELEPHONE ENTRY + ACCESS CONTROL SYSTEM




Surface Mount 1812 / 1812-P / 1812-AP



Flush Mount 1812 / 1812-P / 1812-AP



Surface Mount Curved 1812-P / 1812-AP



Wall Mount 1812 / 1812-P / 1812-AP

Surface

10" W x 6.13" H x 5.25" D
(254mm W x 156mm H x 133mm)

Surface Curved

10.88" W x 7.38" H x 6" D
(276mm W x 187mm H x 152.4mm)

Flush

11.88" W x 9.13" H x 4.5" D
(302mm W x 232mm H x 114mm D)

Wall

10.75" W x 7.38" H x 3.5" D
(273mm W x 187mm H x 88.9mm D)

MODEL	PHONE NUMBERS	DIRECTORY NAMES	ENTRY CODES ¹	DEVICE CODES ²	RELAYS	AUXILIARY INPUTS ³	EXPANSION ⁴	PC PROGRAM ⁵	TEMPORARY CODES	HOLIDAY SCHEDULE
1812	3	N/A	50	0	2	1	No	No	5	No
1812-P	27	N/A	50	0	2	0	No	No	10	No
1812-AP	27	N/A	50	100	2	2	6 Max	Yes	10	Yes

- 1 Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the Entry System Keypad (or Secondary Keypad) only.
- 2 Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the System Keypad.
- 3 1812 auxiliary input allows a switch closure to activate relay 2, or can be set to auto-dial a preprogrammed telephone number. 1812 AP uses a standard RS-485 data input.
- 4 Six (6) additional entry points can be controlled via RS-485 Card Readers, AVID Tag Readers, RF Receivers or Digital Keypads.
5. Programming software included. IP Addressable, programmable via direct connection to PC, LAN or the internet.

Technical Features

Mechanical

Stainless Steel Faceplate
Galvanized Steel Sub-Plate
Metal Keypad
Offset Speaker Holes for protection
Indoor or outdoor applications
Enclosures are NEMA 4x rated
Hands-Free

Electrical

Hands-Free Full Duplex Voice Communication
2-Digit Directory Codes
Unique Ring, Call Waiting, and Call Forwarding
Special Intercom Mode for use with KSU and PBX phone systems
Built-in Time Clock / Calendar
Entry Code Time Zones
Call Forwarding Time Zone
4 Hold Open Time Zones
Do Not Disturb Time Zone
Flash Entry Codes
2 Relays to control 2 Entry Points
Multiple systems may share same Phone Line
Secondary Keypad can be added for entry code access at a second door or gate

1812 Classic

Includes 24 VAC Power Transformer
11-Digit Dialing
Analog Voice Circuit
3 Preprogrammed Call Out Phone Numbers
4-Digit Entry Codes (50)

1812-P & 1812-AP

Includes 16 VAC Power Transformer
20-Digit Dialing
HD Digital Voice Circuit
50 5-Digit Entry Codes with Time Zone Restrictions on some codes
27 Dial-Out Phone Numbers
Answer Machine Bypass Feature

1812-AP

IP Addressable – program from your PC via direct connection, LAN or an internet connection. DKS Connection Services offer easy ways for fast Voice and Data connection over either Cellular, Internet, or POTS.
Intuitive, easy to use, Windows-based programming software included
Add up to 6 Card Readers, Keypads or RF Receivers (RS-485)
100 Card/Transmitter/Keypad codes (50 with phone numbers; 50 Access Codes only)
Up to 30 holidays can be added to Access and Hold Open Time Zones
Control Access Points from your PC. Schedule Lock and Unlock Times, Lock or Unlock an Access Point with the click of a mouse

10 Temporary Access Codes with start and end dates
500 Event Transaction Buffer
Email notification of events of your choice.
Internet connection required

Miscellaneous

Environmental: 10°F to 145°F (-12°C to 62°C)
Camera Ready: Optional CCTV Camera*
*may require additional CCTV equipment
Shipping weight approximately 15 lb (7 kg)



FCC (US) DUF6VT-12874-0T-0
DOC (CAN) 1736 4507 A



1812 Classic



1812 Plus



1812 AP

Distributed by:

MEMBER:



DOORKING®, INC.

120 Glasgow Avenue, Inglewood, California 90301 U.S.A.

Tel: 310-645-0023 FAX: 310-641-1586 www.doorking.com

© 2018 All Rights Reserved. Product specifications may change without notice. Rev. 4/18